

# SLYK®

## Table-Wall Stand Instruction Manual

### Introduction

Thank you for purchasing the SLYK® Table and Wall Stand. This is a unique product that will transform how you use your smart devices hands-free.

The SLYK® Table and Wall Stand will enable use of your devices around your home or office. It has been designed and perfected to be practical, easy to use and hold your devices securely. It works on any firm horizontal surface, like a desk, table or worktop, and works with Apple iPhones and iPads, and all smartphones and tablets, whatever the manufacturer.

### Assembly

The SLYK® Table and Wall Stand comes in two parts, the flexible arm and the base.



There is a screw-bolt attached to the flexible arm. You need to unscrew the bolt with a cross-headed screwdriver and put the screw-bolt to one side.



Gently push the hexagonal nut at the end of the flexible arm through the hexagonal hole in the base.



The flexible arm and the base should now be sitting snugly together



Re-use the screw-bolt you removed to fix the two components together, from the underside. It should not need over tightening, but just enough to secure the flexible arm firmly in place.



The stand is now operational as a table stand.



The black screws in the packet are for the wall bracket to be fixed to a wall (longer screws), or a wooden cupboard/wardrobe/plinth (shorter screws). If you position the bracket so that it is horizontal on the wall, level and with the protruding part facing outwards and above the screw holes, this becomes the holder and the stand base slots into it.



With the bracket secured in your chosen place you can simply align the stand slightly above the bracket flush against the wall and slide it down so that the bracket and the lip on the underside of the base interlock. The stand will support a tablet or a smartphone and the position of the device can be easily adjusted for comfortable hands-free viewing and use.

*Note 1: Carefully removing the protective film from the head you will expose the nano-suction pad. This material creates miniature 'vacuums' when you press your device against it, holding it firmly in place. Devices will be held for many hours and can be removed by simply lifting a corner of the device to 'pop' the device away from the stand, thereby breaking the vacuums. The pad can be 'refreshed' easily. Simply wrap some tape, sticky side outwards around one hand and dab the surface to remove any dust particles and the pad will regain its original suction.*

*Note 2: You should ensure that the device has as clean a surface as possible to attach to the nano-suction pad.*

*Note 3: The head can be rotated 360 degrees, to suit portrait, landscape or angled viewing, and the flexible arm allows the height and orientation to be adjusted further.*

*Note 4: There are also some adhesive pads to use to affix the bracket to a wall, instead of screws, if you do not want to damage your wall or wooden surface.*

# SLYK®

## Table-Wall Stand Instruction Manual

### Care of your product

The silicone cover on the Table and Wall Stand base is a supple material so it needs to be handled with care. It can attract dust and other small particles and should only be wiped clean with a soft damp cloth, free of cleaning products.

### Caution

- Do not expose this product to high or low temperatures
- Do not expose this product to direct sunlight for extended periods to avoid bleaching or degrading its components
- Do not immerse this product in water
- This product is not suitable for children under three years of age
- This product is not a toy - if used by children under 14 years of age then they must be supervised at all times
- Do not use abrasive or bleach-based products when cleaning
- Do not use on rough surfaces - this may damage the silicone covering
- Do not put sharp objects near the silicone cover as they may cause it damage
- Exercise care when the stand is holding a device - it may become separated from the stand and may slip or fall.

### Warranty

This Limited Warranty applies to physical goods purchased from SLYK (the “physical goods”) and covers defects in material or workmanship under normal use during the Warranty Period.

During the Warranty Period SLYK will repair or replace at no charge, products or parts of a product that prove defective because of improper materials or workmanship, under normal use and maintenance, using new or refurbished replacement parts.

The Warranty Period for physical goods purchased from SLYK is 30 days. A replacement of the physical goods, or part thereof, assumes the remaining warranty of the original physical goods of 30 days from the date of replacement or repair.

This Limited Warranty does not cover any problem that is caused from natural disasters, user negligence, unauthorised modifications of the product, or theft of a product and/or loss of the product.

### Returns and Refunds

#### Returns

You have 30 calendar days from the date you received it to return an item. To be eligible for a return, your item must be unused and in the same condition that you received it. Your item must also be in the original packing, undamaged and accompanied by the receipt or proof of purchase.

#### Refunds

Once we receive your item, we will inspect it and notify you that we have received your returned item. We will immediately notify you on the status of your refund after inspecting the item (in this connection please see our Limited Warranty which appears on our [slyk.co.uk](https://www.slyk.co.uk)). If your return is approved, we will issue a refund to your credit card (or the original method of payment). You will receive the credit within the amount of days within your card issuer’s policy.



This product is capable of being recycled, it does not guarantee that the material will be accepted by your local recycling centre or collection service. It does not signify that the product is made from recycled materials.

SLYK LTD – Registered in England and Wales, Company Number: 11703977  
Registered Address: 16 Beaufort Court, Admirals Way, Canary Wharf, London, E14 9XL



@slykltd



@slykltd



@slykltd